OPERATION GUIDELINES

- 1) Place objects inside the unit.
- 2) Choose desired power setting.

NOTE: Do not turn on unit when it is empty. Pour in adequate cleansing liquid (around 1 cm below the rim). Too much liquid may cause it to spill over electronic parts thus damaging the unit.

30W Power Setting

- a. Press POWER to put unit in standby mode. With "99" flashing on the display screen.
- b. Then press the POWER button again to start the 30W cleaning setting . The "99"seconds cleaning time starts, and will stop automatically at "00".

50W Power Setting

- a. Press POWER to put unit in standby mode. With "99" flashing on the display screen.
- b. Then press the POWER button again, when unit starts working under the 30W cleaning setting . Press the 30W/50W button once to switch it to the 50W setting. Then the "99"seconds cleaning time starts, and will stop automatically at "00".
- 3) To stop the unit (under any setting) immediately, just press the POWER button once.
- 4) After cleansing, pull off plug first before taking out cleansed objects
- 5) Clean and dry ultrasonic cleaner after every use.

NOTE: A two minute rest is required after 5 minutes of continuous use . A ten minute rest would be needed after operating it 5 times.

DOUBLE POWER ULTRASONIC CLEANER

INSTRUCTION MANUAL

Thank you for purchasing 9050 Ultrasonic Cleaner.
Please read the manual before using the unit.
Keep manual in accessible place for future reference.

- Clean. removes dirt and greases.
- Sanitize and sterilizes.
- Stops emulsification.
- Innovative lid that is resistant to acid and alkali base.

Manufacturer:

AOYUE TONGYI ELECTRONIC EQUIPMENT FACTORY

Jishui Industrial Zone, Nantou, Zhongshan City, Guangdong Province, P.R.China http://www.aoyue.com

PURPOSE

- Designed to clean small electronic parts and PCB's.
- Can also be used to clean jewelry, watches, eyeglasses and other accessories.
- Can also be used to clean small spare parts.

SPECIFICATION

PowerInput:	240V / 50 Hz
Power Consumption:	30W / 50W
Operation Frequency:	40 k Hz
Tank Capacity:	500 mL
Working Time:	99 seconds
Tank to Ground Resistance:	≤0.1Ω
Tank Dimension:	165(w) x 85(h) x 45(d) mm
Exterior Dimensions:	185(w) x 150(h) x 100(d) mm
Weight:	1 Kg



Use only Aoyue genuine replacement parts, to assure product performance.

FEATURES

- Microprocessor controlled.
- Uniquely designed with anti-static function.
- Versatile with two interchangeable power settings: 30W and 50W.
- Digital display of power, working time and working state.
- Driven by continuous high frequency ultrasound for highly effective cleaning result.

CARE and SAFETY PRECAUTIONS



CAUTION: Misuse may cause extensive damage to the unit. For your own safety, be sure to comply with the following precautions.

- Upon using, please make sure that the plug is properly grounded .
- Do not disassemble/modify unit, high voltage pressure inside unit may cause damages.
- Do not turn on when it is empty. Pour in adequate cleansing liquid. (around 10mm below the rim)
- Do not pour flammable / acidic cleansing liquid.
- Handle with Care
 - Never drop or sharply jolt the unit.
 - Do not beat or drum the bottom of the cleaner.
- Disconnect plug when not to be used for a long period of time.
- It Is normal that the bottom part of the unit gets warm while operating.